

diner-scale

LIMESCALE REMOVER



Uses

Removes limescale residues found in kettles, urns, bain maries etc.

Application

Fill the appliance which requires de-liming with water. Add Diner-scale to the water according to the recommended dilution. Bring water to boiling point. Discard water and rinse appliance with fresh water before use.

Dilution

100ml:10lt water

Supplies

5lt container – 02715

Notes

Suitable for use in the food-processing industry. For use only in acid resistant appliances.

Compounds

- <16% acids
- <2% amphoteric surfactants
- Colourants

Hazardous components

- None

Storage

Store away from foodstuffs. Protect from sunlight and do not expose to temperatures exceeding 50°C.

Technical specifications

Description	Result
Colour	Yellow
pH in concentrate	0.5 ± 0.5
Temperature stability	
Cold	- 20°C
Hot	+ 50°C
Specific gravity at 20°C	1.080 g/ml

Specifications and details are subject to change without prior notice